

2011	C = celková délka (mm)	délka do středu uzamykacího nosu A+B (mm)
▶	Cylindrické vložky EDZ, KDZ	
	54	27 + 27
	58	27 + 31
	62	31 + 31
	63	27 + 36
	67	31 + 36
	68	27 + 41
	72	31 + 41
	72	36 + 36
	73	27 + 46
	77	31 + 46
	77	36 + 41
	82	31 + 51
	82	36 + 46
	82	41 + 41
	87	41 + 46
	87	31 + 56
	87	36 + 51
	92	31 + 61
	92	36 + 56
	92	41 + 51
	92	46 + 46
	97	36 + 61
	97	31 + 66
	97	41 + 56
	97	46 + 51
	102	51 + 51
	102	41 + 61
	102	46 + 56
	102	36 + 66
	102	31 + 71
	107	31 + 76
	107	46 + 61
	112	56 + 56
	112	51 + 61
	122	61 + 61
▶	Cylindrické polovložky EHZ	
	36	+ 27
	41	+ 32
	46	+ 37
	51	+ 42
	56	+ 47
	61	+ 52
	66	+ 57
	71	+ 62
	76	+ 67
	81	+ 72
	86	+ 77

